

FIND OUT HOW TO USE YOUR NEW INTERCOM!

YOUR ACCESS

OPEN THE DOOR Hold your fob in front of the reader.



If you have a **hands-free fob** the door opens **automatically** within a radius of 1 m.

.....

.....

Door opening confirmed by a written message on the intercom screen + voice message « THE DOOR IS OPEN ».

LOST FOB?

Notify your housing manager as soon as possible: They will deactivate your fob to ensure secure access to your residence.



YOUR VISITORS' ACCESS

Your visitors select your name using the arrows

Then press 💢

If you have a push-button intercom,



as they have to do is press the button corresponding to your name.

You receive either an AUDIO CALL or a VIDEO CALL



TID .

Remember to save the intercom phone number in your phonebook after the 1st call, so that you can easily identify calls from your intercom. This number starts with +33 6 or +33 7 and is between 10 and 14 digits long.

AUDIO CALL FROM A LANDLINE OR CELL PHONE

3

*

When your intercom calls you on your landline of

When your intercom calls you on your landline or mobile phone, **PICK UP THE RECEIVER AND FOLLOW THE INSTRUCTIONS BELOW :**

Open your door by pressing *** *unless your housing manager has modified the key

Press the key O to talk to your visitor

Press the key o if you do not wish to open the door



IF THERE IS NO REPLY: :

Your answering machine will not be triggered and the call will be transferred to the 2nd registered number after the 4th ring. In both cases, the answering machine is not triggered.

To receive video calls, download the « My Intercom introtone » free app





PICK UP to accept the call from your smartphone



TALK to your visitor.



OPEN the door OR HANG UP.



IF YOU DON'T ANSWER THE VIDEO CALL, the intercom will call you on audio on the same number. If you don't answer this 2nd call, it will call you on video and then on audio on the 2nd number registered with your housing manager. In both cases, the answering machine is not triggered.

GOOD TO KNOW

Remember to activate your WIFI in case of insufficient network coverage (min 3G).



WOULD YOU LIKE TO ADD MORE USERS **OR ADDITIONAL DEVICES ?**

subject to your housing manager subscribing to the video option

via « My Intercom intratone » app





NEED HELP to install « My Intercom introtone » app ?

DOWNLOAD THE FREE APP



App Store





2 CONFIGURE THE APP




• Click on « **CONTINUE** » to accept the general terms and conditions of use and the data protection policy.

2. Enter your phone number (the one given to your housing manager) the phone number of the number of th

 Enter the security code received by text message



GOOD TO KNOW: If you do not authorise these settings, the app will not allow you to receive calls or open the door



FIND THE CONFIGURATION « My Intercom introtone» app **IN VIDEO:**







R This product comes from sustainably managed forests and controlled sources / pefc-france.org Photo credits PEXELS and FREEPIK I Non-contractual photos I Studio Rose Citron for COCELEC ZEUK-FLY24-01